

INSTALLATION & ADJUSTMENT

of

Exapta[®]s K.311 & K.312 Mojo Wires[™]

for planter “Quick Attach” Keeton seed firmer tails

Assembly:

- 1) Carefully grind off the hooks & loops (see photo).
- 2) Install Quick Attach mounting bracket onto row unit.



- 3) If using liquid tubing, first route it from manifold thru row unit, then thru Ktn bracket and upper hole in tail, then thru pair of plastic Mojo blocks, then into passageway in rearward portion of tail. Install red emitter if you wish.

Note: For a leak-free system, don't do any splicing of the 1/4" tubing. Instead, run a continuous piece from the manifold all the way to the tail. (Or use a good auto-lock union connector.)

Thick-wall black 1/4" tubing is highly recommended; it's more durable than blue or red. Protect pinch or abrasion-prone points on row unit with oversize tubing.



Blue tubing used here for visibility. Customers are strongly encouraged to use thick-wall black tubing instead, for durability.

- 4) Position Mojo Wire & install hose clamps as shown. *Tighten hose clamp so that worm screw is on top and not hanging over the side of tail.* After

tightening clamp, gently tap the underside of clamp to flatten and conform it to the tail. Tighten clamps again **(the clamps can't handle a lot of torque – use a nut-driver instead of a ratchet)**. Flex the tail a couple times, then retighten clamps.



Install when not using the liquid feature.