

INSTALLATION
of
Exapta[®]'s UniForce™
hydraulic downforce system
for **Houck hitches** pulling a pair of box drills

The hose protectors should be located as shown. Slide the hoses and wiring thru them, and secure with zip-ties.



2) Cut off ~2" of pipe handle, or else it will gouge into the hoses.



3) If hitch is equipped with hydraulic weight transfer, secure the hoses away from the cylinder or they'll get pinched, as has happened in the photo.