

INSTALLATION & ADJUSTMENT
of
C101 L&R Steel brackets

to mount Drill Keeton on P500/2080

1. Loosen the two bolts attaching scraper to opener but do not remove them.
2. Install C101 bracket by carefully removing the rear bolt with one hand while holding spacer washers in place with the other hand. Once bolt is removed insert the bolt into the rear hole of C101 bracket and reattach bolt with bracket. Tighten finger tight while keeping spacer washers in place.
3. Remove front bolt. Align front hole of C101 bracket with front hole of scraper, reinsert bolt and tighten.
4. Attach plastic Keeton receiver to C101 steel bracket with bolts provided and tighten. (photo G) Keeton tail can be attached to the plastic receiver during this assembly.
5. See YouTube video [Case P-500 & NH2080 Exapta upgrades.](#)

