

INSTALLATION

of

Exapta[®]s DuraLok[™] firming wheel

on JD 50/60/90 drills

The chamfer side of the hub should be away from the arm – this is because the blade and gauge wheel fling soil towards the bearing and head of the bolt on this side of the wheel, and we want it to easily fall away.

